FLOAT FACTORY

DRIVER'S MANUAL



It's not you. It's your floats.

Like most groundbreaking companies that changed the world, (Google, Space-X, Hot Pockets, etc.)

Float Factory set out to solve a simple, yet insurmountable problem: To end boring days in the water.

Swans, Pizza Slices, Unicorns..... How much longer must we be forced to conform to mediocre water toys?

Humanity was ready for change and no one was doing anything about it..... Until now.

Realizing that this was their higher calling, our founders Patrick and Tommy immediately quit their cushy corporate jobs and chose to focus on nothing but solving this crisis. They decided to wage war on pathetic and lame water toys and traded in their business suits for bathing suits..... (Yes, it was legendary.)

They received all the standard advice from their biggest supporters....

"You're absolutely out of your mind." - Financial advisor

"You're doing what!?" - Ex-Boss

"You can do anything you set your mind to." - Mom

"It's impossible, you'll need an MBA." - Everyone else.

Despite the overwhelming support, they knew they had to follow their dream, and against all odds, Float Factory was born.

Not the heroes we wanted, but the heroes we deserve.

Welcome to #FloatNation, where no float is too crazy, and everyone has the chance to be a kid again.

How will you float with us?




-Patrick & Tommy

PS - Please send all your absolutely most ridiculous ideas to our number one employee and largest supporter; mom@floatfactory.co

FORMULA FLOAT


FLOAT SPECS



HYDRO-MOTOR

ENGINE INSTALLATION & USE

NOT INCLUDED



SET UP INSTRUCTIONS

"STEP 1

Unfold vour Formula Float onto a flat service and put on your racing suit. (Bathing suit)

STEP 2

Using our Float Factory Air Pump, (sold separately), a hair dryer with cool air, or an inflation device of your choice. Inflate the lower value located at the base of Formula Float. Ensure it is tightly sealed once inflated.

STEP 3

IMPORTANT (If Hydro-Motor is purchased) Before inflating the body of your formula float. insert your Hydro Motor into the rear chamber. Flip the on switch forward and seal the motor casing. Then proceed with inflating the body.

STEP 4

Inflate the three additional air chambers in this order: Spoiler, Cockpit, Steering Wheel. ensure all valves are tightly sealed prior to submerging into water.



[For Hydro-Motor Owners] - Attach your remote control in one of your armrest housings and direct your controller in the direction you want to race in and off you go!





Be one of the first to reserve one of your hydro-Motor motor. (Limited supply)



Do not leave out in the sun or in extreme heat for extended periods of time. You don't want your car to overheat!



Drive your friends around in your new ride. Maximum capacity up to 300lbs



Do not fully front load your Formula Float with extra passengers or you will bottom out under water.



Fully extend your legs and lean back against your headrest for ultimate comfort



Do not forget to wash down and store safely. Take care of your new ride!



Challenge other floats to aquatic races. Be the champion of the water!



Do not forget to share your races on social media! Tag us afloatfactoryco



NO PROTECTION AGAINST DROWNING! THIS IS NOT A LIFESAVING DEVICE!

Failure to follow all Warnings, Prohibitions, Mandatory Actions and Instructions throughout this manual can result in serious injury or death. Read the entire owner's manual prior to using your Float Factory Inflatable.





NOT a lifesaving device. NO PROTECTION against drowining.



DO NOT over inflate. See inflation instructions for proper inflation technique.



Risk of getting entrapped if size is not appropriate.



Read instructions first.
Please read this entire
instruction manual prior to
enjoying your Float Factory
Inflatable



Completely inflate each air chamber. Open all air chambers fully prioir to inflation. See inflation instruction section for proper technique.



Completely inflate each air chamber. Open all air chambers fully prioir to inflation. See inflation instruction section for proper technique.

Only to be used in water in which the child is within it's depth & under adult supervision Not for children under the age of 5 years old. NEVER leave children unattended.

To be inflated by an adult. Dangers if not correctly inflated.



Float Factory Inflatables are intended for use by one person at a time, unless otherwise noted on the inflatable and the inflatable's box.



Max load capacity is 300 pounds or 136 kilograms for per inflatable.



Maintain a safe distance to shore of 6 feet or 2 meters. Please remember Float Factory inflatables are for swimmers only and should NEVER be used in an offshore wind or offshore current





Do not use in offshore wind



Do not use in offshore current



Do not use in whitewater



Do not use in breaking waves.







BRAND AMBASSADOR PROGRAM

\$\$Time for your first place winnings! \$\$

Scan below to see how you can make the big bucks and score free products before anyone else!

SCAN TO APPLY

